

Valance, Smoothing Kit, Full Overlay
07-08 Silverado 900 Series

PACKING LIST

Before installation, use this checklist to make sure all necessary parts have been included.

ITEM	QTY	CHECK	PART NUMBER	DESCRIPTION
1.	1	<input type="checkbox"/>	010095211	Valance, Smoothing, Full, Sierra/Silverado 07-08 900 Series
2.	2	<input type="checkbox"/>	12000011	Adhesion Promoter
3.	1	<input type="checkbox"/>	*****	Instructions

NOTE: SLP RECOMMENDS THAT ALL PIECES BE TEST FIT ONTO THE VEHICLE BEFORE PAINTING TO DETERMINE FITMENT AND FINAL POSITIONING OF THE PIECE. FOLLOW THE PAINT MANUFACTURES INSTRUCTIONS FOR PAINTING ABS. ADHERE STRICTLY TO THE PAINT MANUFACTURES DRYING TIME BEFORE ATTEMPTING INSTALLTION. FAILURE TO FOLLOW THESE INSTRUCTIONS MAY RESULT IN IMPROPER FIT OR MAY REQUIRE THE KIT TO BE REMOVED AND REINSTALLED.

INSTALLATIONINSTRUCTIONS - #11781

- 1 Begin the install by thoroughly washing the front of the vehicle with soap (preferably dish detergent) and water to remove all road dirt. Use a quality bug and tar remover to remove any stout road dirt that may be left after the valance is washed.
- 2 Next use the supplied adhesion promoter on the stock bumper in the areas where the tape will need to adhere to the overlay. Allow the adhesion promoter a minute to dry before attempting to install the SLP overlay on the vehicle, see photo 1 below of overlay with tape scheme.



Photo 1: SLP Valance with Tape & Backing

- 3 With the aide of a helper, install the SLP overlay onto the factory chrome bumper. Once the SLP overlay is in place press firmly to fully adhere the tape to the stock bumper, see photo 2 below.



Photo 2: SLP Overlay Installed

4 The installation is now complete! ENJOY!