

Part No. 22100
C.A.R.B. EO # D-187-5

THROTTLE BODY FLOW BOOSTER

PACKING LIST

<u>Item #</u>	<u>Check</u>	<u>Quantity</u>	<u>Part Number</u>	<u>Description</u>
1	<input type="checkbox"/>	1	22100C	SLP Flow booster
2	<input type="checkbox"/>	1	22100B	Flowbooster Mounting Lug
3	<input type="checkbox"/>	1	22100A	10-24 X 2" stainless steel bolt
4	<input type="checkbox"/>	1	*****	Instructions

INSTALLATION INSTRUCTIONS

1. Remove bolts that hold top plate of throttle body and pry top plate off . Be careful when removing plate so as not to damage gasket.
2. Install flowbooster mounting lug through hole in center of top of throttle body.

NOTE: Place in hole with pointed edge down and flat surface towards mouth of the throttle body.

3. Install flowbooster with counter sunk hole towards top of throttle body .
NOTE : Tighten stainless steel bolt to 10 to 15 in. lbs. SLP advises that a high temperature "loctite" be used on bolt.
4. Reinstall top plate of throttle body . Use Chiltons or service manual for proper torque specs on bolts .