

BASIC - Installation requires only rudimentary mechanical skills. If you can follow instructions and have a few basic tools, you should be able to install this product with minimal difficulty.

ESTIMATED INSTALLATION TIME - Installation times are for a professional installer. Times may vary based on the skill level of the installer.

ESTIMATED INSTALL TIME - .2 hrs

PART NO. 23065

SLP Performance
Camaro/Firebird
Smooth Bellows

PACKING LIST

Item #	Check	Quantity	Part Number	Description
1	<input type="checkbox"/>	1	100064740	Smooth Bellows
2	<input type="checkbox"/>	1	*****	Installation Instructions

INSTALLATION INSTRUCTIONS

1. Remove the worm clamp from the stock bellow at the intake.
2. Remove the worm clamp from the stock bellow at the MAF sensor.
3. Pull stock bellow off both the intake and the MAF sensor, replace with new SLP Performance smooth bellow.
4. Install both original worm clamps back on the MAF sensor and the intake. Make sure the new SLP smooth bellow is pushed far enough on the air box and MAF sensor that the clamps have sufficient material to clamp down. (reference photo below.)

