

PART NO. 31035

2000-2002 Camaro/Firebird Stainless Replacement Y-Pipe

Packing List

Item #	Check	Quantity	Part Number	Description
1.	_____	1	310610117	Pipe, D-Side, Front, W/Ball Flange
2.	_____	1	310610118	Y-Pipe, Short, 2000-2002, LS1 F-Body
3.	_____	1	31035K	Install Kit
4.	_____	1	*****	Instructions

Warning: SLP recommends wearing safety glasses for the complete installation.

Warning: SLP recommends allowing the vehicle to cool (not running) for five hours before beginning the installation. SLP recommends wearing safety glasses for the complete installation.

Warning: Too avoid the chance of electrical shock or damage to your vehicle's electrical system, disconnect both the negative and positive battery leads (in that order) at the battery.

Installation Instructions

1. Disconnect the negative battery cable.
2. Raise and support the vehicle. A vehicle lift is highly recommended for this installation.
3. From the under side of the vehicle loosen band clamp at the joint where intermediate pipe joins the outlet of the O.E.M. Y-pipe. Remove the brace that hangs below this joint. Slide the intermediate pipe and muffler assembly rearward until the slip joint comes apart.
4. Loosen and unbolt each of the two flanges at the catalytic converter assembly outlets and remove the OEM Y-Pipe from the vehicle.
5. Next install the driver's side elbow onto the outlet of the flange at the catalytic converter assembly.
6. Next install short Y-Pipe onto the outlet of the driver's side elbow and onto the outlet of the passenger's side flange at the catalytic converter assembly.
7. Used the supplied clamp to secure the driver's side elbow to the short y-pipe.
8. Slide the muffler assembly and intermediate pipe forward.
9. Check for clearances to all body parts and tighten down each clamp, nut and bolt.
10. The installation is now complete.