

**Bracket, 1993-02 Camaro License Plate**

PACKING LIST

*Before installation, use this checklist to make sure all necessary parts have been included.*

ITEM	CHECK	PART NUMBER	QTY	DESCRIPTION
1.	<input type="checkbox"/>	503880001	1	License Plate Bracket
1.	<input type="checkbox"/>	50265	4	¼"-20 Nylon Lock Nut
1.	<input type="checkbox"/>	325020075	4	¼"-20 Phillips Bolt
1.	<input type="checkbox"/>	325020001	2	¼" USS Flat Washer
1.	<input type="checkbox"/>	*****	1	Instructions

**INSTALLATION INSTRUCTIONS – #59388**

1. Begin by marking the two spots on the underside of the front fascia for drilling as follows: Hold the offset (stepped) side of the bracket up against the underside of the fascia, with the bracket centered on the “point” of the fascia nose, and the backside of the vertical leg of the bracket, approximately 3/8" away from the “point”. While the bracket is properly positioned, carefully mark the underside of the fascia through the holes in the bracket.
2. Using a ¼” drill, drill the two marked holes through the underside of the fascia.
3. Remove the three expanding plastic pins at the underside rear edge of the fascia. This will allow access to the topside of the holes you drilled.
4. Using two ¼"- 20 Phillips bolts, two ¼"-20 nylon lock nuts and the two ¼" USS flat washers, mount the bracket to the fascia (AS SHOWN IN ILLUSTRATION).
5. Using the remaining two ¼"-20 Phillips bolts and two ¼"-20 nylon lock nuts, mount the license plate to the bracket.

