

**PART NO. 70005**

**1993-2002 V8 Camaro/Firebird  
Strut Tower Brace (Excluding  
1996-1997 Camaro SS)**

PACKING LIST				
Item #	Check	Quantity	Part Number	Description
1	<input type="checkbox"/>	1	210124003P	Strut Tower Cross Brace
2	<input type="checkbox"/>	4	300124001	Flat Washer, 1/2" SAE
3	<input type="checkbox"/>	1	*****	Instructions

**Warning:** SLP recommends allowing the vehicle to cool for several hours before beginning the installation. Exhaust components and brakes can be extremely HOT and could cause severe burns if it is not allowed to cool. SLP also recommends wearing safety glasses for the complete installation. Refer to GM service manuals for further pictures or specifications.

**INSTALLATION INSTRUCTIONS**

1. Remove the front two flange nuts (refer to Illustration 1) from the studs on the top surface of each strut tower.
2. Place one 1/2" SAE flat washer on each of the four studs. This will allow the cross brace's base to clear the additional stamped metal on the strut towers alongside the studs and sit flat on the strut tower.
3. Install the strut tower cross brace by locating the mounting holes over the four studs. Center the slotted holes in the two base plates on the studs.
4. Re-install the four flange nuts on studs and torque each to 43 Nm (32 ft o lb). A 'crows foot' style wrench can be used to torque the inner bolt.